



2025 BYD LEOPARD 5 ULTRA

2025 BYD LEOPARD 5 ULTRA

PERFORMANCE

- 5-Seater SUV Plug-In Hybrid 4x4
- 1,200 km Range Combined
- 1.5L Turbocharged 4-Cylinder Engine
- Dual Motor AWD (200 kW + 250 Kw)
- 680 Horsepower. 760 Nm Torque
- DC Fast Charging Time 15 minutes (125km)
- 0-100 km/h in 4.8 seconds
- 20-inch Rims, Pirelli Tires
- Front & Rear Differential Lock, 4Low
- Sport+ Mode & Off-Road Modes, Wading Mode

FEATURES

- Intelligent Driving System
- Heated & Ventilated Front Seats with Massage
- Devialet Sound System
- Heated Steering Wheel
- Panoramic Roof with Power Sunroof
- 50-inch Head-Up Display
- Adaptive Cruise Control with Radar
- 360 Camera with Parking Sensors with Auto Park
- Lane Keep Assist, Lane Change Assist
- Bluetooth Phone Set
- Tire Pressure Monitoring System
- Passenger Screen, Fridge, Child Lock
- Interior Ambient Lighting
- 50W Wireless Phone Charging Pads
- Electric Side Steps, Roof Rails
- Rear Heated and Ventilated Seats



























Plug-in Amount
30.9 kWh

Fuel Consumption
11.4 L

262 kPa 35°C
262 kPa 27°C
242 kPa 27°C
247 kPa 26°C
Please adjust the tire pressure to standard value

复位 +
设定 -

菜单 | P

语音 | 电话


导航 | 媒体

* | 设置

模式

越野

AIRBAG



03:36

30°C



OK



km/h

P

EV
请您在使用产品前将产品保护膜移除
Please remove the protective film before use



Plug-in
Amount



30.9

kW·h

Fuel
Consumption



11.4

L



262 kPa

252 kPa

35°C

27°C

242 kPa

247 kPa

27°C

26°C

Please adjust the tire
pressure to standard value


76%

75 km

159 km

1 kW

ODO 26 km





SQH879241906-PAD 显示屏总成
040J521TKS30950849

请您在使用产品前将产品保护膜撕掉!
Please remove the protective film before using!



Door Lo...
Unlocked



Trunk
Closed



Drive
Mode



106.8 MHz



Phone Link



Home

Charge



Lo

Lo

Lo

Lo

Lo

Lo

Lo

Lo


Lo

Lo

Lo

Lo

Lo

















请使用92#或以上标号无
铅汽油
USE 92# ABOVE UNLEADED
FUEL ONLY













充电指示灯 CHARGING INDICATOR

- | | |
|--|---|
|  充电连接中闪烁
Connecting flashing |  预约充电
Schedule |
|  充电中闪烁
Charging flashing |  放电中闪烁
Discharging flashing |
|  充电完成
Completed |  充电故障
Failure |



① 充电前请确认车辆解锁，停止充电。
② 充电失败时，请参考用户手册。
③ 充电失败时，请关闭充电口盖。
④ Please unlock the car and stop
charging before pulling the vehicle
connector.
⑤ If unlock failed, please refer to the
user manual to manually unlock.
⑥ Please close the charging port
cover when not charging.









